

## MANUAL GRIPFACTORY MICROGRIP CONCRETE

**ATTENTION:** The room must be well ventilated.

**ATTENTION:** Read the safety data sheet before starting.

### TOOLS REQUIRED:

- Personal protective equipment (protective gloves and panoramic glasses)
- Watering can, wax coat, brush, vacuum cleaner and / or floor cleaner
- Pressure sprayer with GripFactory MicroGrip Concrete (non-slip liquid for concrete and stone)
- GripFactory MicroGrip Cleaner (cleaning agent)

### IMPLEMENTATION:

- Clean the floor with MicroGrip Cleaner (see manual MicroGrip Cleaner).
- Spray the MicroGrip Concrete evenly over the floor with a pressure sprayer.
- spread the MicroGrip Concrete over the floor with a wax coat without leaving any streaks.
- Allow the MicroGrip Concrete to work in for around 15 minutes without the floor drying. If there are dry spots, spread the liquid with the wax coat or spray the liquid.
- After 15 minutes, neutralize the floor with water and scrub the floor thoroughly.
- Then dry the floor with a wet vacuum cleaner or floor squeegee.

### TIPS:

- Always first make a test surface out of sight so that the effect of the anti-slip treatment is known.
- Beware of dark floors because of the “whitening” effect.
- Make sure the floor heating is off and prevent drafts as much as possible.
- Never treat more than 100 m2 per session to achieve the correct skid resistance everywhere.



GripFactory B.V.

Industrieweg 4 H  
3442 AE Woerden  
The Netherlands

☎ +31 (0)348 - 20 30 00

✉ [info@gripfactory.nl](mailto:info@gripfactory.nl)

🌐 [www.gripfactoryantislip.com](http://www.gripfactoryantislip.com)

### GRIPFACTORY APPLICATION SERVICE

Problems, issues? Then contact the GripFactory Service Desk (+31 348 203000). For an additional cost you can have GripFactory MicroGrip applied by a certified applicator.