

## MANUAL GRIPFACTORY MICROGRIP MARBLE

**ATTENTION:** The room must be well ventilated.

**ATTENTION:** Read the safety data sheet before starting.

### TOOLS REQUIRED:

- Personal protective equipment (protective gloves and panoramic glasses)
- Watering can, brush, wax coat, vacuum cleaner and / or floor cleaner
- Pressure sprayer with GripFactory MicroGrip Marble (anti-slip liquid for marble)
- GripFactory MicroGrip Cleaner (cleaning agent)

### IMPLEMENTATION:

- Clean the floor with MicroGrip Cleaner (see manual MicroGrip Cleaner).
- Depending on the surface, dilute the MicroGrip Marble 1:5 or 1:10.
- Spray the MicroGrip Marble evenly over the floor with a pressure sprayer.
- Spread the MicroGrip Marble over the floor with a wax coat without leaving streaks.
- Allow the MicroGrip to work in for around 30-45 minutes without the floor drying. If there are dry spots, spread the liquid with the wax coat or spray the liquid.
- Test after 30 minutes whether the floor's roughness is sufficient. For a higher skid resistance, let the liquid work in even longer.
- If the floor is sufficiently rough, neutralize with water and scrub the floor thoroughly.
- Dry the floor afterwards with the vacuum cleaner or floor extractor.

### TIPS:

- Always first make a test surface out of sight so that the effect of the anti-slip treatment is known.
- Beware of dark floors because of the "whitening" effect.
- Make sure the floor heating is off and prevent drafts as much as possible.
- Never treat more than 100 m<sup>2</sup> per session to achieve the correct skid resistance everywhere.



GripFactory B.V.

Industrieweg 4 H  
3442 AE Woerden  
The Netherlands

☎ +31 (0)348 - 20 30 00  
✉ [info@gripfactory.nl](mailto:info@gripfactory.nl)  
🌐 [www.gripfactoryantislip.com](http://www.gripfactoryantislip.com)

### GRIPFACTORY APPLICATION SERVICE

Problems, issues? Then contact the GripFactory Service Desk (+31 348 203000). For an additional cost you can have GripFactory MicroGrip applied by a certified applicator.